



50 Series Standard Brake Instructions



Figure 1. 50 Series Brake

Standard Housing		Wt. Lbs.		Inertia Rotating Parts
Model	Torque Lb-F.	Net	Pkg'd	WK ² in Lb-Ft ²
				51001-050
51003-050	3	6	7	.002
51006-050	6	6	7	.002

Table 1. List of Models

IMPORTANT

Read this bulletin carefully before installing or operating this brake. Failure to comply with these instructions cancels all warranties.

WARNING

Brake performance and features must be carefully matched to the requirements of the application. Consideration must be given to torque requirements, especially where an overhauling condition exists, as well as thermal capacity, ambient temperature, atmospheric explosion hazards, type of enclosure and any other unusual conditions. Improper selection and installation of a brake and/or lack of maintenance may cause brake failure which could result in damage to property and/or injury to personnel. If injury to personnel could be caused by brake failure, additional means must be provided to insure safety of personnel. Do not operate manual release or energize brake coil before installation, in order to preserve prealignment of rotating discs for ease of installation.




Figure 2. Dimensions of Brake

DESCRIPTION

This brake is direct acting, electromagnetically released and spring set. It uses rotating and stationary disc contact to supply positive braking action. It retains quick release and setting capabilities at all times.

Simplicity of design has reduced maintenance to an absolute minimum. As with any electromechanical equipment, however, periodic inspection and adjustment will assure optimum performance. As the friction disc wears, the magnet gap will increase. The magnet gap should be checked periodically and adjusted when necessary.

INSTALLATION (See Figures 2, 3, 4 & 5)

Before installing, refer to section on Torque Selection.

1. Remove hub (2) from brake and position on motor shaft with key per dimension shown in Figure 2. Stamped part number on hub should face away from motor. Tighten hub set screws to shaft with 6-8 lb. ft. torque.

2. Remove the three cover screws (3) and cover (4) and position brake over hub (2) on shaft. Bolt brake to motor flange with two 1/4" flat head screws. (NOTE: Be sure anti-rattle spring (5) does not rest in hub tooth space containing a set screw.)

3. Connect coil wire leads as indicated in Figure 3. Replace cover and three cover screws.

MANUAL RELEASE (See Figure 4)




Figure 3. Wiring Diagram

Manually release the brake by pushing the release lever (1) forward until it has moved approximately 25°. The brake will remain in the released position as long as you hold the lever in this position.

MAINTENANCE AND SERVICE

FRICITION DISC REPLACEMENT (See Figure 4)

When total wear on rotating discs (11) reaches 1/16", replace disc as follows:

1. Remove the three cover screws (3), cover (4), nuts (9), magnet assembly (8), washers (10), nuts (12), torque springs (13), armature (14), nut (7), nut (6), pressure arm (15) and stationary disc (16).

2. Install new rotating disc (11) making sure anti-rattle spring (5) is installed in position shown and does not rest in a hub tooth space containing a set screw.

3. Reassemble all parts in reverse order.

NOTE: In reassembly, tighten nut (6) so that it just makes contact with pressure arm (15). LOCATE nut (12) 1/2" from end of stud as shown in Figure 4. Tighten nut (9) as described under MAGNET ASSEMBLY REPLACEMENT. Readjust magnet air gap as described under WEAR ADJUSTMENT.




Figure 4. Brake Gap Adjustment

WEAR ADJUSTMENT (See Figure 4).

As friction disc wears, magnet air gap "A" increases. When air gap "A" reaches .150" maximum, adjust to .060"-.070". To adjust: Hold pivot nut (6), loosen lock nut (7), turn pivot nut (6) clockwise until air gap "A" measures .080" at center of magnet. (NOTE: Air gap should decrease slightly to measure .060"-.070". When lock nut (7) is tightened against the pivot nut (6).) Hold pivot nut (6) and tighten lock nut (7) against it. Operate brake several times to see if .060"-.070" air gap is maintained. If not, re-adjust following same procedure again. Any delay in adjusting air gap will result in a loss of torque and/or coil burn out.

MAGNET ASSEMBLY REPLACEMENT (See Figure 4)

Remove cover screws (3), cover (4), nuts (9) and magnet assembly (8). Replace magnet assembly. Be sure rubber pads (10) are under magnet bracket. Tighten nuts (9) to remove end play between nut and magnet bracket. Tighten with an additional 1/3 turn (two flats on nut). Check air gap as described under WEAR ADJUSTMENT and replace cover and cover screws.




Figure 5. Exploded View of Brake

Table 2. Parts List

ITEM NO.	PIECES REQ'D	NET WT. PER PIECE	DESCRIPTION	PART NO.
1	1	1 oz.	RELEASE LEVER	G050073-001
2	1	4 oz.	SPLINED HUB W/ SET SCREWS (SPECIFY BORE & KEYWAY)	H050038
3	3	1 oz.	MACHINE SCREW, PAN HD. WITH LOCKWASHER	W001006-022
4	1	12 oz.	COVER	K050043-004
5	1	1 oz.	ANTI-BACKLASH SPRING	H060466-001
6	1	1 oz.	PIVOT NUT	G060267-001
7	1	1 oz.	LOCKNUT	W003001-018
8	1	21 oz.	MAGNET ASSEMBLY (INCLUDES ITEM 23)	Specify voltage
9	2	1 oz.	LOCKNUT	W003001-015
10	2	1 oz.	RUBBER WASHER	G060310-001
11	1	2 oz.	ROTATING DISC	H050028-001
12	2	1 oz.	NUT, HEX	W003002-002
13	2	1 oz.	TORQUE SPRING - SILVER - (MODEL 2-51001-050)	G050076-001
13	2	1 oz.	TORQUE SPRING - BRONZE - (MODEL 2-51003-050)	G050077-001
13	2	1 oz.	TORQUE SPRING - OLIVE - (MODEL 2-51006-050)	G050078-001
14	1	5 oz.	ARMATURE ASSEMBLY	H050034-002
15	1	8 oz.	PRESSURE ARM ASSEMBLY	H050036-002
16	1	3 oz.	STATIONARY DISC	G050074-001
17	1	24 oz.	BRACKET ASSEMBLY	K050047-001
18	2	1 oz.	RETURN SPRINGS	G050075-001
19	1	1 oz.	COMPRESSION SPRING	G050107-001
20	4	1 oz.	BRASS WASHER	W004003-020
21	1	1 oz.	NAMEPLATE	K060210-001
22	1	1 oz.	SEAL (WHEN USED) - NOT SHOWN	G050111-001
23	1	1 oz.	SHADING COIL	G060346-001

